


JOCHUM & NESLER
SPORTING GOODS



- (A) Chicken loop
- (B) Quick release
- (C) Chicken stick
- (D) Turnable bar ends
- (E) 3D grip bar
- (F) Floaters
- (G) Adjuster handle
- (H) Adjuster
- (I) Oh'shit handles
- (J) Back lines
- (K) Depower line
- (L) Safety line
- (M) Center line
- (N) Front line
- (O) 5th line
- (P) Attachment line
- (Q) Dyneema Y



WARRANTY

In order to validate the JN warranty and to demonstrate that you have taken notice of its limitations, please complete the following warranty card with details and return it to JN within 30 days from the purchase, or register online within the same period at www.jn-kites.com or inform us by e-mail (info@jn-kites.com) about all necessary details.

Please send to: Jochum & Nesler GmbH / Gampenstrasse 97m / 39012 Meran / Italy

NAME
ADDRESS
CITY
ZIP CODE
STATE / PROVINCE
COUNTRY
E-MAIL
PRODUCT
SERIAL NUMBER
PURCHASE DATE

WARNING & RELEASE OF LIABILITY

Kitesurfing is an extreme sport and exposes users to unavoidable risks and dangers. Please be aware of the possibility of severe or even deadly injuries, respect the sport and its dangers.

Before using this product, the user has carefully reviewed the security advices. He understands them and agrees to comply with them. The user of this product understands that the seller / producer is not responsible for any damage to property or injury caused by negligent operation of this product by the user and releases the seller / producer from all such liability.

At rental or propagation to other users, every user has to read, understand and agree with the above conditions. Don't use this product if you don't agree with these terms and conditions. Kindly return the product before use within 7 days and your purchase price will be refunded in full.

MODE CONVERSION: 4 LINE MODE 1

The Switchcraft II (4 lines preassembled) comes set up like shown at picture 1. A release of the QR will lead to sheeting out at one frontline!

Recommended for:

- all swept back shapes (Mr. Fantastic)
- all Bow kites
- all 4 line C-Kites



MODE CONVERSION: 4 LINE MODE 2

Modify your Switchcraft II from four line mode 1 (picture 1) with safety release by one frontline to four line mode 2 with safety release by both frontlines (picture 3). A release of the QR will lead to sheeting out at both frontlines!

Recommended for:

- high depower kites
- swept back Shapes (Mr. Fantastic)



MODE CONVERSION: 5 LINE MODE

Modify your Switchcraft II from four line bar (picture 1 and 3) to five line bar. Therefore apply the included 5th line as shown below (picture 5). A release of the QR will lead to sheeting out at the fifth line!

Recommended for:

- five line C-Kites (Prima Donna)
- five line swept back shapes (Mr. Fantastic)



BACK LINE MODE

To kite safe for rider and kite in waves we recommend a sheet out at a back line. Therefore attach your leash at the Oh'shit handles at the backlines. Possible for 4 line and 5 line mode.

TURNABLE BAR ENDS

By using both loops at the bar ends you can adjust two different line lengths. Loosening the screws allows to turn the bar ends additionally, so as result; four different bar lengths are available.

42 cm →	5 m ² – 7 m ²
46 cm →	9 m ² – 11 m ²
50 cm →	11 m ² – 13 m ²
54 cm →	13 m ² – 15 m ²

For further questions please visit the download section on www.jn-kites.com or ask your local dealer. Have fun!

The JN Team

